



Appendix for DNC260-Presets CoRAY 130110

MEM	Preset Name	PGM Type	Out 1 (Source)	Out 2 (Source)	Out 3 (Source)	Out 4 (Source)	Out 5 (Source)	Out 6 (Source)
1	CoRAY4-L	stereo	CoRAY4 FR (A)	CoRAY4 FR (A)	CoRAY4 FR (A)	CoRAY4 FR (B)	CoRAY4 FR (B)	CoRAY4 FR (B)
2	CoRAY4-Lx2	stereo	CoRAY4Fx2 (A)	CoRAY4Fx2 (A)	CoRAY4Fx2 (A)	CoRAY4Fx2 (B)	CoRAY4Fx2 (B)	CoRAY4Fx2 (B)
3	CR+CR-L-L	stereo	CR or CR-L (A)	CR or CR-L (A)	CR or CR-L (A)	CR or CR-L (B)	CR or CR-L (B)	CR or CR-L (B)
4	CoRAY4+G15	stereo	CoRAY4 (A)	G15x130 (A)	CoRAY4 (A)	CoRAY4 (B)	G15x130 (B)	CoRAY4 (B)
5	CoRAY4x2+G15	stereo	CoRAY4x2 (A)	G15x130 (A)	CoRAY4x2 (A)	CoRAY4x2 (B)	G15x130 (B)	CoRAY4x2 (B)
6	CR+CR-L+G15	stereo	CR or CR-L (A)	G15x130 (A)	CR or CR-L (A)	CR or CR-L (B)	G15x130 (B)	CR or CR-L (B)
7	CR4xG18o100	stereo	CoRAY4 (A)	G18 (A)	CoRAY4 (A)	CoRAY4 (B)	G18 (B)	CoRAY4 (B)
8	CoRAY4x2+G18	stereo	CoRAY4x2 (A)	G18 (A)	CoRAY4x2 (A)	CoRAY4x2 (B)	G18 (B)	CoRAY4x2 (B)
9	CR+CR-L+G18	stereo	CR or CR-L (A)	G18 (A)	CR or CR-L (A)	CR or CR-L (B)	G18 (B)	CR or CR-L (B)
10	CoRAY4+SC4	stereo	CoRAY4 (A)	SC4 (A)	CoRAY4 (A)	CoRAY4 (B)	SC4 (B)	CoRAY4 (B)
11	CoRAY4x2+SC4	stereo	CoRAY4x2 (A)	SC4 (A)	CoRAY4x2 (A)	CoRAY4x2 (B)	SC4 (B)	CoRAY4x2 (B)
12	CR4x2+SC4-C1	mono	CoRAY4x2 (A)	SC4-Front (Sum)	CoRAY4x2 (A)	CoRAY4x2 (B)	SC4-Rear (Sum)	CoRAY4x2 (B)
13	CR+CR-L+SC4	stereo	CR or CR-L (A)	SC4 (A)	CR or CR-L (A)	CR or CR-L (B)	SC4 (B)	CR or CR-L (B)
14	CR+CR-L+SC4C	mono	CR or CR-L (A)	SC4-Front (Sum)	CR or CR-L (A)	CR or CR-L (B)	SC4-Rear (Sum)	CR or CR-L (B)
17	CR4xG18o140	stereo	CoRAY4 (A)	G18 (A)	CoRAY4 (A)	CoRAY4 (B)	G18 (B)	CoRAY4 (B)
18	CR4x2+G18o14	stereo	CoRAY4x2 (A)	G18 (A)	CoRAY4x2 (A)	CoRAY4x2 (B)	G18 (B)	CoRAY4x2 (B)
45	CoRAY 130110							

Shortcut description	
1	CoRAY4, linear preset
2	CoRAY4 in twin mode, linear preset
3	CoRAY4 + CoRAY4-L, linear preset
4	CoRAY4 + G15-Sub
5	CoRAY4 in twin mode + G15-Sub
6	CoRAY4 + CoRAY4-L + G15-Sub
7	CoRAY4 + G18-Sub with crossover at 100 Hz
8	CoRAY4 in twin mode + G18-Sub
9	CoRAY-L + CoRAY4-L + G18-Sub
10	CoRAY4 + SC4
11	CoRAY4 in twin mode + SC4
12	CoRAY4 in twin mode + SC4 in Cardio mode with crossover at 100 Hz
13	CoRAY4 + CoRAY4-L + SC4
14	CoRAY4 + CoRAY4-L + SC4 in Cardio mode
17	CoRAY4 + G18-Sub with crossover at 140 Hz
18	CoRAY4 in twin mode + G18-Sub with crossover at 140 Hz
45	CoRAY 130110