

Appendix for DNC-Presets LA4 - RC20 Format 111103

MEM	Preset Name	PGM Type	Out 1 (Source)	Out 2 (Source)	Out 3 (Source)	Out 4 (Source)	Out 5 (Source)	Out 6 (Source)
1	L4-L	stereo	Mute (A)	LA4 (A)	LA4 (A)	Mute (B)	LA4 (B)	LA4 (B)
2	L4+Sub	stereo	Mute (A)	LA4-SUB (A)	LA4-L (A)	Mute (B)	LA4-SUB (B)	LA4-R (B)
3	L4+Sub+PW418	mono	Mute (A)	PW418 (Sum)	LA4-L (A)	Mute (B)	LA4-SUB (Sum)	LA4-R (B)
4	L4+Sub+SC4	mono	Mute (A)	SC4 (Sum)	LA4-L (A)	Mute (B)	LA4-SUB (Sum)	LA4-R (B)
45	LA4, 111103							

Shortcut description	
1	LA4 Linear, stereo
2	LA4 + LA4-Sub, stereo
3	LA4 + LA4-Sub + PW418, mono
4	LA4 + LA4-Sub + SC4, mono
7	LA4, 111103